

Botron B7530 Technical Data Sheet



Cup design:

The cup of the Ergo One Heel Grounder is a symmetrical design that can be reversed when put on. It also features a dual layer rubber with a non-marking inside and a conductive rubber outside. As with all of our static control heel grounders the Ergo One Series has a 1.5" wide rubber, securing both at the back and underneath the heel. Its 7.5" length rubber provides enough cup volume to fit comfortably on those with larger shoe sizes.

Fastening System:

This is standard hook and loop velcro system. Measuring .75 wide by 7" in length its ergonomic design is for both comfort and practicality.

Grounding:

Our ESD heel grounders come standard with a conductive 18" ribbon. All resistors are built in and are available in 1meg or 2meg applications, also available in no resistor.



Calle del Ebano #16625
Jardines de Chapultepec
Tijuana B.C. Mexico
Tel. (664) 681 1130
Fax. (664) 681 1150
Tel. 01800 027-4848
www.finaltest.com.mx



Product Notes and Features

- 1) 7" Stretch Hook and Loop for Comfort Fit
- 2) 1Meg, 2Meg or No Resistor Applications
- 3) 1.5" x 7.5" Cup w/ Non-Marking Interior
- 4) 18" Conductive Nylon Ribbon

PROPERTIES

SPECIFICATIONS

Cup Design:	1.5" x 7.5" Two Layer Rubber
Sole Interior:	Non-Marking Rubber
Sole Exterior:	Conductive Rubber 5x10 ³
Ribbon:	18" Conductive Nylon
Charge Decay:	<0.01Sec
Thickness:	0.080
Resistor:	1 MegOhm, 2 MegOhm, and No-Resistor models
RTG (w/ 1Meg):	1.1x10 ⁶
RTG (w/ 2Meg):	2.2x10 ⁶
Standards:	ANSI/ESD S.20.20 & Mil 263
Fastening system:	¾" x 7" Stretch Hook & Loop
Packing:	1 per bag / bags of 10
Colors:	Blue, Black and Yellow

INSTALLATION

1. Unfasten hook & loop strap and slip the rubber cup onto heel, black side down.
2. Fasten the hook & loop strap tightly over top of foot.
3. Trim conductive ribbon to desired length and place inside of sock or shoe. (skin contact is recommended)

RECOMMENDED USAGE

1. For safety reasons, it is recommended that heel grounders be worn on both right and left feet, in order to maintain a continuous path to the ground.
2. Conductive ribbon should be tucked inside the shoe or sock making as much contact with the skin as possible. Please take note, if ribbon is worn outside of the sock to maintain electrical contact, perspiration is needed in order to maintain an electrical contact with the heel grounder.
3. Heel grounders should be used in conjunction with a floor surface, and/or floor mat with a surface resistance less than 1×10^9 .

PART NUMBERS

B7500 Blue velcro 1 MegOhm Resistor
B7501 Blue velcro No Resistor
B7502 Blue velcro 2 MegOhm Resistor
B7510 Black velcro 1 MegOhm Resistor
B7511 Black velcro No Resistor
B7512 Black velcro 2 MegOhm Resistor
B7530 Yellow velcro 1 MegOhm Resistor
B7531 Yellow velcro No Resistor
B7532 Yellow velcro 2 MegOhm Resistor

TESTING GUIDELINES

To properly test your heel grounders it is recommended to clean your heel grounder free of debris. Also check that the conductive ribbon is making adequate skin contact.

Botron recommends testing heel grounders with any of the following test equipment. B82251, B8211, B8225, B8506 and B88000.

If you obtain a fail reading, please check your heel grounder for wear as well good skin contact. Retest after inspection. If the unit still fails, replace the heel grounder.

Botron Company Inc. | 325 W. Melinda Ln Phoenix AZ 85027 | Ph# 623-582-6700 | Fax# 623-582-6776

Disclaimer. All statements of technical information are believed to be true and are based upon tests we believe to be reliable. The proper use and application for this product must be the responsibility of the user.

The statements herein shall have no force or effect.